

## Coastal Bronze 40-300 Gate Latch

Flush mount the strike plate to your post or jamb!!!!



Front handle. Install this to provided bore setting. Insure there is plenty of vertical thumb-lever play



Back assembly. Align the latch bar plate so the latch bar is horizontal and resting on the thumb-lever. Set the latch bar guide with the locking pin set in place to insure the proper locking alignment.



The 40-300 arrives pre-bored with a 1" diameter bore recessed 3/8" deep. This is centered on the 5-1/4" wide stiles. Centered within this bore is a 1/2" x 1-1/8" slot to accomodate the thumb levers (Tail Pieces)